


Instruction Sheet

Extra Parameters:

LED Bulbs Amount: 322 pcs
Total Power: 20W
Voltage: 7.2V-12V
Color Temperature: 5600K/3200K

Components:



1. Dimmer: Dim the light. Two dimmers, each dimmer control half of the light.
2. Battery plate: Suitable for mounting Sony NP-F series battery directly, for Panasonic or Canon battery, a battery adapter is required.
3. Battery balance indicators: Power is at full level if all indicators turn on after pressing the button; less indicators on, lower power level, if no indicators on, battery need to be recharged or replaced.
4. DC Socket: For DC input plug.
5. Mounting Rails: For mounting the light on camera, or mounting camera on the light.
6. Panasonic Battery Adapter: Special for Panasonic CGR-D series battery.
7. AA Battery Pack: Use for 6PCS of AA battery, offer power for the light.
8. Filters: Without filters, light is of spotlight effect and suitable for shooting at a relatively long distance; with diffusing filter, light is of soft light effect; and with yellow filter, the color temperature of light changes from 5600K to 3200K. With Extra Diffusing filter, the light becomes much softer and eliminate shadow effect. The installation method of filter is press and catch type. Filter has two different sides, one side has recess at its short edges, and the other side does not. Put the side with recess towards the LED panel, press the filter to be caught by the filter catcher. Then the filter is fixed.
9. Gels Holder: For packing the diffuser and filter.



Without Filter



Diffusing Filter



Extra Diffusing Filter



Yellow Filter

Instructions:

1. Install Battery: When installing Li-ion battery, please place Li-ion battery with correct side and direction in the battery holder and then press it evenly to make sure it is well installed. When installing AA battery pack, please make sure the positive and negative and negative poles are correct positioned according to the "+" and "-" marks shown. When installing Panasonic battery, the battery adapter must be mounted on the battery holder, so that the Panasonic battery can be installed. After installing the battery, please check the battery power and make sure LED Lighting is workable.
2. When mounting the camera on the long rail, you should pay attention that the lens well matches and properly works in the middle part of the light.
3. When mounting the light on camera, mount the light on the short mounting rail first, insert the hot shoe adapter of short mounting rail into the hot shoe of camera; screw the knob to fix.
4. Adjust light brightness. Rotate the dimmer to turn on the LED Lighting and adjust light brightness. There is two dimmers, each dimmer controls half of the light.
5. Turn off after use.

Notice:

1. Please turn off the power after use, in order to avoid waste of battery and longtime heat generation and further affect the service life of LED bulbs.
2. If power is supplied by AA battery, please remove the battery when the LED Lighting is out of use, otherwise, the battery unused longtime will go moldy and rot the circuit inside the LED Lighting.
3. Please install battery as gently as you can to avoid damage and distortion of the battery holder
4. Please do not hold on the light to lift the DV or camera
5. Please install the battery gently, in order to avoid the battery plate damaged and out of shape
6. Please keep away from dampness